

bosch-ebike.com

# Nyon – the connected all-rounder



**BOSCH**  
Invented for life

# Nyon at a glance








- |                                |                                      |
|--------------------------------|--------------------------------------|
| <b>A</b> Motor performance     | <b>F</b> Connected heart rate sensor |
| <b>B</b> Performance indicator | <b>G</b> Bicycle light switched on   |
| <b>C</b> Current speed         | <b>H</b> Battery charge level        |
| <b>D</b> Time                  | <b>I</b> Remaining range             |
| <b>E</b> Current riding mode   | <b>J</b> Micro-AB-USB port           |

## Use the + and - buttons to select one of 4 assisted riding modes

- |              |   |
|--------------|---|
| <b>Eco</b>   | Effective support for the greatest range                    |
| <b>Tour</b>  | Consistently reliable support for long rides                |
| <b>Sport</b> | Powerful support for universal uses                         |
| <b>eMTB*</b> | Progressive, dynamic support for a natural riding sensation |
| <b>Turbo</b> | Maximum support for a sporty ride                           |

## Functions

-  Navigation  Touch display  Customisation
-  Topographical residual range  Fitness data tracking



The eBike Connect App and the eBike Connect portal open up new options. Log in at [ebike-connect.com](http://ebike-connect.com) and learn more. All functions and details about the Nyon can be found at [www.bosch-ebike.com](http://www.bosch-ebike.com)

bosch-ebike.com

# Kiox – sporty connectivity



**BOSCH**  
Invented for life

# Kiox at a glance



- A** Walk assistance
- B** Cursor buttons: toggle between screens & settings
- C** Select button
- D** Performance indicator
- E** Current speed compared to average speed
- F** Time or speed
- G** Current riding mode
- H** Bicycle light switched on
- I** Battery charge level
- J** eShift (optional)
- K** Current speed
- L** Motor performance
- M** Bicycle light on/off

## Use the + and - buttons to select one of 4 assisted riding modes

- Eco** Effective support for the greatest range
- Tour** Consistently reliable support for long rides
- Sport** Powerful support for universal uses
- eMTB\*** Progressive, dynamic support for a natural riding sensation
- Turbo** Maximum support for a sporty ride

## Functions

📍 Navigation    👤 Personalization    📊 Fitness data tracking



The eBike Connect App and the eBike Connect portal open up new possibilities, such as navigation using the app on the Kiox (available from Model Year 2021). Log in at [ebike-connect.com](https://www.ebike-connect.com) now and find out more.

# Intuvia – clever and clearly arranged



# Intuvia at a glance



- A** Walk assistance
- B** Reset counters
- C** Shift recommendation
- D** Current speed
- E** Battery charge level
- F** Current riding mode
- G** Information button: toggle between the various display options (trip distance, trip time, average, range)
- H** Bicycle light on/off

## Use the + and - buttons to select one of 4 assisted riding modes

- Eco** Effective support for the greatest range
- Tour** Consistently reliable support for long rides
- Sport** Powerful support for universal uses
- eMTB\*** Progressive, dynamic support for a natural riding sensation
- Turbo** Maximum support for a sporty ride



You'll find information on upgrade options for the displays in the enclosed fold-out booklet Expertise. If you don't have this to hand, you'll find the full range of functions and more details at [www.bosch-ebike.com](http://www.bosch-ebike.com)

bosch-ebike.com

# Purion – the compact purist



**BOSCH**  
Invented for life

# Purion at a glance



## Functions

- ⊕ Long press: Light on/off
  - ⊖ Long press: Display trip distance, total distance and range
  - ⊕ Short press: Switch ride modes
  - ⊕ + ⊖ Long press: Reset the trip distance or range display
- A** Current speed  
**B** Range  
**C** Battery charge level  
**D** Activate walk assist, keep ⊕ pressed for support

Click	Short	Medium	Long
	up to 1 sec.	up to 2.5 sec.	more than 2.5 sec.

## Use the + and - buttons to select one of 4 assisted riding modes

- Eco** Effective support for the greatest range
- Tour** Consistently reliable support for long rides
- Sport** Powerful support for universal uses
- eMTB\*** Progressive, dynamic support for a natural riding sensation
- Turbo** Maximum support for a sporty ride



You'll find information on upgrade options for the displays in the enclosed fold-out booklet Expertise. If you don't have this to hand, you'll find the full range of functions and more details at [www.bosch-ebike.com](http://www.bosch-ebike.com)